ACCESSORIES INCLUDED



7” Device | USB cable | Power adapter | Protective Case

CONTROLS AND CONNECTIONS



1. Power
2. Reset
3. Volume +/-
4. USB Host
5. Mini USB
6. Head Phone
7. Micro SD Slot
8. DC-In Jack
9. Menu Key
10. Home Key
11. Backspace Key
12. Search Key
13. Camera
14. Microphone

INSERT MEMORY CARD

NOTICE Please pay attention to the direction you insert the card (see picture), or the device will be damaged. DO NOT take out the memory card when the tablet is on. Content may be lost.

CHARGING



NOTICE As shown in the diagram, make sure that the charge plug is inserted fully. ONLY use the supplied charger or you may damage the tablet.

IMPRESSION 7 ” ANDROID TABLET QUICK START GUIDE

INTERFACE INTRODUCTION

Screen Interface

Main screen interface is similar to a computer desktop.
Place application shortcuts and widgets here.
Touch and “swipe” to go to next page, move things on the screen, etc.
Touch 2 fingers and spread apart or bring together to zoom pictures in and out.

Widgets

Press the screen for “menu” key. The “Add to Home screen” menu will pop up offering you options to add widgets, change wallpaper, etc.

Deleting Application Shortcuts

Press and hold down the application button on the screen. A trash can will pop up on the right side of screen. Drag the application shortcut to the trash.

Status Bar

Pay attention to the status bar on the top of screen. If icons show on the left, it is a reminder that applications are running. On the right of the status bar, there are Widgets

The icon is media refresh

The icon is ScreenSnap

Application List

Click the Application List icon to show the application library.

Touch an application icon to start it up.
Press the “Home” key in the application list interface to return to the home screen.

Safety Advice

If the product emits an unusual odor or excessive heat, or you notice anything else that seems unusual, do not use the product.

Do not use the product near water.

Do not try to open the device or attempt to open and repair the product yourself. It will be damaged.

Please do not put the device near a magnetic field, it will be damaged.

Avoid leaving the product in a hot or humid place. Avoid dropping the unit, it will be damaged.